

QuickStartGuide



Video



Audio



Photos



Games




Settings

Important Notice:

Please ensure that iTeddy is fully charged before commencing. To charge, simply connect iTeddy to the mains or connect via the USB cable to a computer or laptop.









Putting your songs, videos and games on iTEDdy










Connect iTEDdy with your home computer via the 'USB' cable provided. Your computer will automatically recognise iTEDdy, and an icon will appear to show this (*in 'My Computer' on a Windows PC, and directly on the desktop on Mac OSX*). Double click to open, and simply drag your files onto the data folder - iTEDdy will automatically sort the files into their respective folders, leaving you with more time to start having fun!

Getting Started on iTEDdy




Hold  to turn on iTEDdy. After the introduction screen, the iTEDdy menu will appear. From here, all of iTEDdy's features can be accessed - Music, Videos, Pictures, Games and Settings can easily be selected by scrolling with the   buttons, and pressing the  button will choose the selected option.

Control and Navigation

The control functions operate as shown on the shield diagram overleaf. The standard buttons operate as expected in Music and Video modes:

-  is select/play/pause
-  is stop
-  is fast forward/skip to the next track
-  is rewind/skip to the previous track
-  is return to main menu (long press)/return to sub menu (quick press)
-  will switch iTEDdy off (long press)/and also switch iTEDdy on (quick press)
-  activates and deactivates hold mode
-  and  together will reset the player (long press)

In Photo mode and within menus (*including Settings*), the button functions change:

-  and  are used to scroll
-  is select